

# Creative Media Printing Instructions



## General Description

---

Creative media, stickers, magnets, tattoo paper etc for the purposes of arts and crafts, special presentations and display of images on a variety of surfaces such as metal, glass and plastics.

Store paper flat in original packaging to avoid exposure to humidity and dirt. Keep away from direct sunlight and at room temperature.

Printing set up instructions are provided as a guideline. Final results depend on the type of ink used and whether original or compatible.

Some adjustment might be required to the printer driver in order to get the optimal results.

In the very unlikely event that media does not feed in the printer, a gentle push as the printer attempts to pick up the paper might assist in feeding. Worn and contaminated feeding rollers on older printers may also effect feeding. Rollers can be cleaned with acetone or alcohol to improve the feeding of paper.

## Printer Set Up

---

### General:

- These products are suitable for printing on inkjet printers only.
- On Glossy media, print on the glossy side.
- For Matt media, print on the matt side. If both sides look the same, print on the chalkier looking side. If results are poor, try printing on the other side
- Adhesive media is semi permanent. It will adhere well but will not leave a residue when removed.

### Glossy Sticker, Glossy Magnet

#### Epson® Printers:

**Media type:** Photo quality Glossy Film  
Under custom and **advanced** setting please make sure the resolution is 1440 dpi or higher.

#### HP® Printers:

**Media type:** Other photo papers or simply photo paper.  
**Quality:** Best.

#### Canon® Printers:

**Media type:** High Glossy photo film  
Print quality high under custom, set to maximum **fine**

#### Kodak®, Samsung®, Sharp® etc.

Also supported  
Select similar settings as listed above

### Clear Sticker, Clear Acetate/OHP Transparency

#### Epson® Printers:

**Media Type:** Photo Quality Glossy Film or "Ink Jet Transparencies  
**Print Quality:** High print quality of at least 1440 dpi or optimal photo  
For an Epson printer using Claria inks set "Epson matt" and "optimal photo".

#### Canon® Printers:

**Media Type:** Photo high gloss film  
**Print Quality:** High print quality.

#### HP® Printers:

**Media Type:** HP Premium high gloss film  
**Print Quality:** Optimal quality setting

#### Kodak®, Samsung®, Sharp® etc.

Also supported  
Select similar settings as listed above

### Matt Sticker, Matt Magnet

#### Epson® Printers:

**Media Type** - Epson Matte or Photo Quality Inkjet Paper  
**Print Quality** - Photo or Best Photo  
**Colour Control** - Epson Vivid

#### Canon® Printers:

**Media Type** - High Resolution Paper  
**Print Quality** - High  
**Colour Control** - Auto

#### HP® Printers:

**Media Type** - HP Premium Paper  
**Print Quality** - Normal or Best  
**Colour Control** - ColourSmart/sRGB or defaults

#### Lexmark® & Dell®:

**Media Type** - Coated Paper  
**Print Quality** - Normal, Better or Best  
**Colour Control** - Defaults

#### Kodak®, Samsung®, Sharp® etc.

Also supported  
Select similar settings as listed above

### Tattoo Craft Paper

**Print on the matt side (not on the red grids)**

**Follow printing setups as in Matt Sticker and Magnet**

#### Application guidelines

Designed for application of inkjet printed images onto a variety of surfaces and items such as mugs, candles, tiles, models, nails and skin.

- The paper is a fine sticker that needs to be carefully peeled off the carrier **after printing** before application to the substrate or skin
- Cut out the image using scissors
- Carefully peel off the backing with the red grid and carefully apply the sticker to the required surface
- When applying to surfaces such as plastic, wood, metal etc, the image will not be water proof. In order to protect the image, a fixative spray (available from PPD) needs to be used.
- When applying to skin, the result will be affected by oily or hairy areas of the skin, on which application is not recommended.
- The tattoo paper is water resistant, but can be washed off easily using soap

Photo Paper Direct Ltd.

Unit 8, Shakespeare Industrial Estate, Watford, WD24 5RR

T: +44 (0)1923 232 590 E: sales@photopaperdirect.com

Web: [www.photopaperdirect.com](http://www.photopaperdirect.com)

F: [facebook.com/PhotoPaperDirectUK](https://www.facebook.com/PhotoPaperDirectUK) T: [twitter.com/PhotoPaper](https://twitter.com/PhotoPaper) G: [plus.google.com/+photopaperdirect/](https://plus.google.com/+photopaperdirect/)